

# Fitting Instructions


(7400W)





# Fitting Instructions

## Safety Instructions:

1. Loops in pull cords, chains, tapes and inner cords that operate the product can cause strangulation
2. To avoid strangulation and entanglement, keep cords out of the reach of young children. Cords may become wrapped around a child's neck
3. Move beds, cots and furniture away from window covering cords
4. Do not tie cords together. Make sure cords do not twist and create a loop



## 7400W Cord Drawn Window Track:



1. Unpack the track and fix the universal brackets into place using the appropriate screws. Screws must be pan head and if possible insert a washer. The brackets should be 100mm in from either end and spaced at no more than 600mm between.
2. If the track has a join in place, install this before lifting track into place. A second person is required to help lift the track if a join has been used within the track.
3. Lifting the track into place, insert the lugs on the front of the bracket into the back of the track. Once in place, push/turn the locator into place to lock the track onto the brackets.
4. Once the track is installed, put the cord weight onto the cord. If the track is top fix, a fixing must be put through the fixing ring on each of the pulleys.
5. Check that the track operates smoothly and correctly before hanging the curtains.

**NB.** Large curtain tracks are heavy and it is important that the correct fixings are used. If unsure, seek expert advice.

6. Ensure the relevant child safety device is used to comply with BS EN13120:2009+A1:2014, BS EN16433:2014 and BS EN16434:2014.

